

FIELD MAINTENANCE SUPPORT

NUVISTOR CHECKER/BALANCER OPERATION PROCEDURE
(For use with Type 575 Transistor Curve Tracer)

The Nuvistor Checker/Balancer, used in conjunction with the Type 575 Curve Tracer, provides a means of observing a family of characteristic curves. In addition, two nuvistors can be operationally compared for similar characteristics.

This device incorporates 1 k, 1% current sampling resistors between the base and emitter terminals so that the MA/step selector of the Type 575 can be read as V/step directly. The following equations are used to determine the μ and gm of the nuvistor under test:

$$\mu = \frac{\Delta E_p}{\Delta E_g} \quad \text{with } I_p \text{ constant}$$

$$gm = \frac{\Delta I_p}{\Delta E_g} \quad \text{with } E_p \text{ constant}$$

Test Procedure:

Preset the Type 575 as follows:

Vert. Sens: 1 MA/Div
 Horiz. Sens: 10 V/Div (6CW4)
 10 V/Div (7895)
 5 V/Div (7586)

Collector Sweep:

Peak Volts Range 0-200
 Peak Volts Approx. 60%
 Polarity +
 Diss. Lim. Res. 5 k to 50 k

Base Step Generator:

Polarity -
 Step/Family 12
 Step Sel: .05 to .2 MA/Step
 (Read as V/Step)

Plug the Checker/Balancer into the test panel of the Type 575. Remove the indicator light jewel and bulb from the Type 575 and insert the power plug of the Checker/Balancer.

Nuvistor Characteristics: Source: RCA Publications 7586, Feb., 1960;
 6CW4, June, 1960;
 7895, Mar., 1961.

6CW4

Max. Ratings:

$E_p = 110V$
 $P_p = 1 \text{ watt}$
 $I_p = 15 \text{ ma}$

Typical Operation:

$E_p = 70V$
 $I_p = 8 \text{ ma}$
 E_p (for $I_p = 10 \mu a = -4V$)
 $\mu = 68$
 $gm = 12,500 \mu mhos$

7586

Max. Ratings:

$E_p = 110V$
 $P_p = 1 \text{ watt}$
 $I_p = 20 \text{ ma}$

Typical Operation:

$E_p = 40V$
 $I_p = 6.8 \text{ ma}$
 E_g (for $10 \mu a I_p$) = -6.5V
 $\mu = 35$
 $gm = 11,000 \mu mhos$

7895

Max. Ratings:

$E_p = 110V$
 $P_p = 1 \text{ watt}$
 $I_p = 20 \text{ ma}$

Typical Operation:

$E_p = 110V$
 $I_p = 7 \text{ ma}$
 E_g (for $10 \mu a I_p$) = -4V
 $\mu = 64$
 $gm = 9,400 \mu mhos$